A. Pair your thermostats

1. Install ecoControl Homey app


2. Add thermostats by '+' icon

3. Select type of thermostat to be paired (PRO, FLAT, OLED, Wireless sensor)

4. Search and select correct ones. Sometimes you must do several search operations. Some rare cases you must restart ecoControl app from Homey app settings

2.	3.	4.

inventions
for a more comfortable world

TAELEK

B. Best practices to use Homey with Tsense

1. Deactivate thermostat's internal 24/7 program (user program 'OFF') with mobile app

2. OLED →
      Adjust always comfort setpoint in Homey flows and in Homey programs. Use eco mode and eco setpoint <u>only</u> in cases you want to override everything. I.e. the best practise in Homey 24/7 program is adjust comfort setpoint of Tsense and not to swap bethween comfort and eco modes.

2. All other thermostat models →
      In dislayless models Homey cannot modify comfort setpoint (rotate the knob). Homey can control only eco setpoint (green indication on thermostat). You must always force eco mode in Homey and adjust eco setpoint. If you see red in thermostat Homey is NOT controlling it.

Normal/comfort mode

Eco mode (green indication on displayless thermostats)

Back   Aikku   ⚙

WHITE = NORMAL OPERATION, BLACK = FORCED ECO

Back   Aikku   ⚙

WHITE = NORMAL OPERATION, BLACK = FORCED ECO